Shop Manual

CEBM033904

980E-5

DUMP TRUCK

SERIAL NUMBERS **980E-5** **A50137 - A50140**

This material is proprietary to Komatsu and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

KOMATSU

© Copyright 2024 Komatsu Ltd.
or one of its subsidiaries
All Rights Reserved
Printed in the U.S.A.

DUMP TRUCK

980E

Machine model	Serial number
980E-5	A50137 - A50140

00 Index and foreword
Index

Composition of shop manual 2
Table of contents 4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.
The marks shown to the right of Form No. denote the following:
□: New module (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:
- Place a divider on the top of each section in the file after matching the Tab No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	CEBM033904 ●
00 Index and foreword	
Index	CEN00064-04 ●
Foreword, safety and general information	CEN00051-04 ●
01 Specification	
Specification and technical data	CEN01030-02
10 Structure and functions	
Steering circuit	CEN10062-03
Hoist circuit	CEN10067-02
Brake circuits	CEN10068-02
Electrical system, 24 volt	CEN10107-00
Automatic lubrication (auto lube) system	CEN10080-01
20 Standard value table	
Standard service value table	CEN20012-01
30 Testing and adjusting	
Steering, brake cooling and hoist hydraulic system	CEN30071-06
Brake system	CEN30072-07
Accumulators and suspensions	CEN30098-17 ●
Electrical systems	CEN30102-04
Interface module 2 (IM2)	CEN30125-05 ●
KOMTRAX Plus II	CEN30091-02
Payload meter IV	CEN30070-05
Komatsu Wireless Bridge (KWB)	CEN30101-00
KomVision	CEN30105-03
Cab air conditioning	CEN30029-02
Automatic lubrication (auto lube) system	CEN30129-01

40 Troubleshooting
- Fuse, diode and relay locations CEN40199-02
- Troubleshooting by fault code, Part 1 CEN40178-03
- Troubleshooting by fault code, Part 2 CEN40179-04
- Troubleshooting by fault code, Part 3 CEN40180-03
- Troubleshooting by fault code, Part 4 CEN40181-04
- Troubleshooting by fault code, Part 5 CEN40182-03
- Steering system CEN40104-09
- KomVision CEN40200-01
- Automatic lubrication (auto lube) system CEN40202-01
- Electronic fan clutch CEN40256-02

50 Disassembly and assembly
- Service tools CEN50046-11
- Wheels, spindles and rear axle CEN50107-05
- Brake system CEN50023-04 ●
- Steering system CEN50045-03 ●
- Suspensions CEN50049-03
- Hoist circuit CEN50110-01
- Body and structures CEN50105-03
- Operator cab CEN50108-01
- Power module CEN50138-01

90 Diagrams and drawings
- Hydraulic circuit diagrams CEN90014-03
- Electrical circuit diagrams CEN90053-00

Table of contents

00 Index and foreword
Index CEN00064-04
Composition of shop manual 2
Table of contents 4
Foreword, safety and general information CEN00051-04
Foreword 4
How to read the shop manual 5
General safety 7
Precautions before operating the truck 10
Precautions while operating the truck 12
Working near batteries 15
Precautions before performing service 17
Precautions while performing service 21
Tires 23
Precautions for performing repairs 26
Precautions for welding on the truck 27
Control cabinet capacitor discharge system 28
Handling electrical equipment and hydraulic components 30
Standard tightening torques 38
Conversion tables 44

01 Specification
Specification and technical data CEN01030-02
Specification drawing 3
Specifications 4
Weight table 6
Fuel, coolant and lubricants 7

10 Structure and functions
Steering circuit CEN10062-03
Steering circuit operation 3
Steering circuit components 8
Steering/brake pump operation 10
Flow amplifier operation 14
Hoist circuit CEN10067-02
Hoist circuit operation 3
Hoist circuit components 4
Hoist pilot valve operation 8
Brake circuits CEN10068-02
General information 3
Service brake circuit operation 4
Secondary braking 7
Automatic brake application (Auto apply) 7

This is the sample of the manual

Click on the download link for complete manual

Download Link

Parking brake circuit operation....8
Wheel brake lock circuit operation....9
Brake warning circuit operation....9
Electrical system, 24 volt CEN10107-00
Battery supply system....3
Isolation box....4
Engine starting system with prelube....5
Auxiliary control cabinet components....6
Body-up switch....9
Hoist limit switch....9
Automatic lubrication (auto lube) system CEN10080-01
General information....3
System operation....4

20 Standard value table
Standard value table CEN20012-01
Standard value table for truck....3

30 Testing and adjusting
Steering, hoist, brake cooling and auxiliary hydraulic system CEN30071-07
Hydraulic system bleeddown procedure....3
Hydraulic system vacuum procedure....5
General information on system checkout....6
Hydraulic system checkout procedures....7
Hydraulic system checkout data sheet....18
High altitude steering pump adjustment....21
Toe-in adjustment....22
Measuring steering pin joint wear....23
Hoist cylinder leakage test....26
Steering cylinder leakage test....26
Brake system CEN30072-07
General information on system checkout....3
Brake system checkout procedures....3
Brake system checkout data sheet....15
Brake piston leakage test....24
Brake seal pressure test....24
Oil separator seal pressure test....24
Wet disc brake bleeding procedure....25
Parking brake bleeding procedure....26
Service brake disc wear inspection....27
Parking brake disc wear inspection....28
Brake valve bench test and adjustment....29
Dual relay valve bench test and adjustment....32
Accumulators and suspensions CEN30098-17
Accumulator charging and storage....3
Bladder accumulator charging procedure....4

Piston accumulator charging procedure....8
Piston accumulator storage....11
Piston accumulator leak testing....12
Checking for improper suspension charge on operating trucks....13
Suspension oil change recommendations....14
Suspension oiling and charging procedures....15
Suspension pressure test....27
Electrical systems CEN30102-04
General information on system checkout....3
Truck shutdown procedure....4
Required software and tools....4
Electrical system checkout procedures....6
Electrical checkout sheet....12
Interface module 2 (IM2) CEN30125-05
Required tools....3
Programming the IM2....3
Interface module checkout procedures....5
IM checkout sheet....10
KOMTRAX Plus II CEN30091-02
Required software and tools....3
Ethernet connection to KOMTRAX Plus II controller....3
KOMTRAX Plus II configuration....5
GPS connection test....7
Iridium satellite system opening....9
Data download over ethernet connection for KOMTRAX Plus II initialization....12
Payload meter IV CEN30070-05
Payload meter IV software and tools....3
Payload meter IV system configuration....3
Payload meter IV software installation....5
Inclinometer calibration and clean truck tare....6
Payload meter IV checkout procedure....6
PLM IV system checkout data sheet....12
Downloading PLM IV data and possible errors....13
Komatsu wireless bridge (KWB) CEN30101-00
General information....3
Required software and tools....3
Configuring the Bullet wireless radio....4
Installing the Bullet wireless radio....7
Configuring the NanoStation access point....8
Testing the connection....11
Changing a service computer's IP address....12
KomVision CEN30105-03
Requirements....3
Initial setup....4
Checkout data sheet....13
Calibration sheets....18

Camera calibration procedures 25
Radar setting procedure 35
Cab air conditioning CEN30029-02
General information 3
Service tools and equipment 4
Detecting leaks 7
System performance test 8
Checking system oil 9
System flushing 10
Installing the manifold gauge set 11
Recovering and recycling refrigerant 12
Evacuating the air conditioning system 14
Charging the air conditioning system 15
Automatic lubrication (auto lube) system CEN30129-01
Priming the system 3
Checkout procedure 4
Adjusting the lubrication cycle timing 5

40 Troubleshooting
Fuse, diode and relay locations CEN40199-02
Vehicle Electrical Center (VEC-89) 3
Vehicle Electrical Center (VEC-90) 5
Vehicle Electrical Center (VEC-91) 7
Vehicle Electrical Center (VEC-92) 8
Rear Terminal Mini-fuse and Relay (RTMR3) 10
Rear Terminal Mini-fuse and Relay (RTMR4) 11
Circuit breakers 11
Troubleshooting by fault code, Part 1 CEN40178-03
Fault Code A001 4
Fault Code A002 5
Fault Code A003 6
Fault Code A004 7
Fault Code A005 8
Fault Code A006 9
Fault Code A007 10
Fault Code A008 11
Fault Code A009 12
Fault Code A010 13
Fault Code A011 14
Fault Code A013 15
Fault Code A014 16
Fault Code A016 17
Fault Code A017 18
Fault Code A018 19
Fault Code A019 20
Fault Code A022 21

Fault Code A100....22
Fault Code A101....23
Fault Code A103....24
Fault Code A104....25
Fault Code A105....26
Fault Code A109....27
Fault Code A111....28
Fault Code A115....29
Fault Code A117....30
Fault Code A118....31
Fault Code A123....32
Fault Code A124....33
Fault Code A125....34
Fault Code A126....35
Fault Code A127....36
Fault Code A128....37
Fault Code A139....38
Troubleshooting by fault code, Part 2 CEN40179-04
Fault Code A145....4
Fault Code A146....5
Fault Code A152....6
Fault Code A153....7
Fault Code A154....8
Fault Code A155....9
Fault Code A158....10
Fault Code A166....11
Fault Code A167....12
Fault Code A168....13
Fault Code A169....14
Fault Code A170....15
Fault Code A171....16
Fault Code A172....17
Fault Code A173....18
Fault Code A184....19
Fault Code A190....20
Fault Code A193....21
Fault Code A194....22
Fault Code A195....23
Fault Code A196....24
Fault Code A197....25
Fault Code A198....26
Fault Code A199....27
Fault Code A200....28
Fault Code A201....29
Fault Code A202....30
Fault Code A203....31

Fault Code A204 32
Fault Code A205 33
Fault Code A206 34
Fault Code A207 35
Fault Code A213 36
Fault Code A214 37
Fault Code A215 38
Fault Code A216 39
Fault Code A223 40
Fault Code A230 41
Fault Code A231 42
Fault Code A233 43
Fault Code A235 44
Fault Code A236 45
Fault Code A237 46
Fault Code A238 47
Fault Code A239 49
Fault Code A240 51
Fault Code A242 52
Fault Code A243 53
Fault Code A244 54
Fault Code A245 55
Fault Code A246 56
Troubleshooting by fault code, Part 3 CEN40180-03
Fault Code A247 4
Fault Code A248 5
Fault Code A249 6
Fault Code A250 7
Fault Code A251 8
Fault Code A252 9
Fault Code A253 10
Fault Code A256 11
Fault Code A257 12
Fault Code A258 13
Fault Code A260 14
Fault Code A261 15
Fault Code A262 16
Fault Code A264 17
Fault Code A265 18
Fault Code A266 19
Fault Code A267 20
Fault Code A268 21
Fault Code A270 22
Fault Code A271 23
Fault Code A272 25
Fault Code A273 26

Fault Code A274....27
Fault Code A275....28
Fault Code A277....29
Fault Code A278....30
Fault Code A279....31
Fault Code A280....32
Fault Code A281....33
Fault Code A282....34
Fault Code A283....35
Fault Code A284....36
Fault Code A285....37
Fault Code A286....38
Fault Code A292....39
Troubleshooting by fault code, Part 4 CEN40181-04
Fault Code A303....4
Fault Code A304....5
Fault Code A305....6
Fault Code A307....7
Fault Code A309....8
Fault Code A310....9
Fault Code A311....10
Fault Code A312....11
Fault Code A313....12
Fault Code A315....13
Fault Code A316....14
Fault Code A317....15
Fault Code A318....16
Fault Code A328....17
Fault Code A332....18
Fault Code A333....19
Fault Code A334....20
Fault Code A335....21
Fault Code A337....22
Fault Code A338....23
Fault Code A339....24
Fault Code A340....25
Fault Code A341....26
Fault Code A342....27
Fault Code A343....28
Fault Code A344....29
Fault Code A345....30
Fault Code A346....31
Fault Code A347....32
Fault Code A348....33
Fault Code A349....34
Fault Code A350....35

Fault Code A351 36
Fault Code A352 37
Fault Code A353 38
Fault Code A354 39
Fault Code A355 40
Fault Code A356 41
Fault Code A357 42
Fault Code A358 43
Fault Code A359 44
Fault Code A360 45
Fault Code A361 46
Fault Code A362 47
Fault Code A363 48
Fault Code A364 49
Fault Code A365 50
Fault Code A366 51
Troubleshooting by fault code, Part 5 CEN40182-03
Fault Code A400 4
Fault Code A401 5
Fault Code A402 6
Fault Code A403 7
Fault Code A404 8
Fault Code A405 9
Fault Code A406 10
Fault Code A407 11
Fault Code A408 12
Fault Code A409 13
Fault Code A410 14
Fault Code A411 15
Fault Code A412 16
Fault Code A413 17
Fault Code A414 18
Fault Code A415 19
Fault Code A416 20
Fault Code A417 21
Fault Code A418 22
Fault Code A419 23
Fault Code A420 24
Fault Code A421 25
Fault Code A422 26
Fault Code A423 27
Fault Code A424 28
Fault Code A425 29
Fault Code A426 30
Fault Code A427 31
Fault Code A428 32

Fault Code A429....33
Fault Code A430....34
Fault Code A431....35
Fault Code A432....36
Fault Code A433....37
Fault Code A434....38
Fault Code A435....39
Fault Code A436....40
Fault Code A437....41
Fault Code A438....42
Fault Code A439....43
Fault Code A440....44
Fault Code A441....45
Fault Code A442....46
Fault Code A443....47
Fault Code A444....48
Fault Code A445....49
Fault Code A446....50
Fault Code A447....51
Steering system CEN40104-09
Steering circuit troubleshooting chart....3
Steering circuit troubleshooting guidelines....5
Basic hydraulic system checks....6
System leakage check....7
Steering pump troubleshooting guide....9
Pump pressure control checks....12
KomVision CEN40200-01
KomVision fault codes....3
Automatic lubrication (auto lube) system CEN40202-01
Auto lube troubleshooting chart....3
Electronic fan clutch CEN40256-02
Electronic fan clutch troubleshooting....3
Electronic fan clutch fault codes....5

50 Disassembly and assembly
Service tools CEN50046-11
Special tool group....3
Heated body tool group....3
Additional service tools....4
KomVision calibration tools....4
Locally made tools....4
Wheels, spindles and rear axle CEN50107-05
General precautions for tires and rims....3
Wheel stud maintenance....4
Rear outer wheel stud installation....5
Removal and installation of front wheel....6

Removal and installation of rear wheel 8
Rim and tire service 11
Removal and installation of front wheel hub and spindle 26
Disassembly and assembly of front wheel hub and spindle 33
Floating seal assembly and installation 52
Removal and installation of rear axle 62
Removal and installation of anti-sway bar 65
Removal and installation of pivot pin 68
Pivot eye and bearing service 70
Removal and installation of wheel motor 72
Installation of wheel motor 75
Removal and installation of rear brake assembly 79
Brake system CEN50023-04
Removal and installation of brake valve 3
Disassembly and assembly of brake valve/pedal assembly 5
Removal and installation of dual relay valve 8
Removal and installation of brake manifold 11
Disassembly and assembly of brake manifold 12
Removal and installation of piston brake accumulator 13
Disassembly and assembly of piston brake accumulator 17
Disassembly and assembly of front wheel brake 21
Disassembly and assembly of rear wheel brake 27
Brake floating ring seal assembly and installation 35
Removal and installation of parking brake 42
Disassembly and assembly of parking brake 44
Steering system CEN50045-03
Removal and installation of steering control unit 3
Disassembly and assembly of steering control unit 6
Removal and installation of steering column 11
Removal and installation of steering wheel 13
Removal and installation of bleeddown manifold 14
Removal and installation of flow amplifier 16
Removal and installation of steering cylinders 17
Disassembly and assembly of steering cylinders 19
Removal and installation of tie rod 23
Removal and installation of steering/brake pump 26
Removal and installation of piston steering accumulator 29
Disassembly and assembly of piston steering accumulator 34
Suspensions CEN50049-03
Removal and installation of front suspension 3
Disassembly and assembly of front suspension 12
Removal and installation of rear suspension 17
Disassembly and assembly of rear suspension 23
Hoist circuit CEN50110-01
Removal and installation of hoist pump 3
Disassembly and assembly of hoist pump 8

Removal and installation of hoist valve 17
Disassembly and assembly of hoist valve 19
Overcenter manifold service 27
Removal and installation of hoist pilot valve 28
Disassembly and assembly of hoist pilot valve 31
Removal and installation of hoist cylinders 33
Disassembly and assembly of hoist cylinders 39
Body and structures CEN50105-03
Removal and installation of dump body 3
Removal and installation of body pads 6
Removal and installation of diagonal ladder/hood and grille assembly 8
Removal and installation of RH deck 10
Removal and installation of LH deck 12
Removal and installation of fuel tank 14
Removal and installation of fuel gauge sender 17
Removal and installation of hydraulic tank 18
Removal and installation of hydraulic tank strainers 20
Operator cab CEN50108-01
Removal and installation of operator cab 3
Removal and installation of cab door 6
Disassembly and assembly of cab door 8
Adjustment of cab door 18
Removal and installation of side window glass 21
Removal and installation of windshield and rear window glass 24
Removal and installation of windshield wiper components 25
Removal and installation of cab seats 27
Removal and installation of seat belts 29
Power module CEN50138-01
Removal and installation of power module 3
Removal and installation of alternator 18
Engine / alternator attachment checkout data sheet 29
Additional engine measurements 31
Removal and installation of the cooling module 35
Repairing the radiator 40
Removal and installation of engine 43
Removal and installation of electronic fan clutch 47
Removal and installation of electronic fan clutch speed sensor 48

90 Diagrams and drawings
Hydraulic circuit diagrams CEN90014-03
Steering, hoist and brake cooling hydraulic circuit schematic 58B-60-21400
Brake hydraulic circuit schematic 58F-60-00841
Auxiliary system hydraulic circuit schematic 58E-60-01680
Electrical circuit diagrams CEN90053-00
Electrical circuit diagram 58B-06-05901
HVAC circuit diagram 58B-06-06830

This is the sample of the manual

Click on the download link for complete manual

Download Link